


91-162 Function schematic seat back locking system (coupe)



— Suction line
- - - Control line

8 Check valve
10 Restrictor
11 Distribution piece
17 Connection piece
22 Distribution piece

44 Door contact vacuum switch
46 Vacuum switch (driver's seat back)
51 Vacuum element (seat)
54 Operating rod
73 Intake manifold

